


INSERTS EV

■ BSH-F



Article no.	Dnom(MM)	L(MM)	J(MM)	A(MM)	Exec
A006060	M10	60	25	35	EV
A006061	M12	70	30	40	EV
A006062	M16	100	35	32	EV
A006063	M20	100	35	40	EV



■ BSH



Article no.	Dnom(MM)	L(MM)	J(MM)	A(MM)	Exec
A006070	M8	50	20	30	EV
A006071	M10	60	25	35	EV
A006072	M12	45	25	18	EV
A006073	M12	70	30	40	EV
A006074	M16	60	30	24	EV
A006075	M16	100	35	32	EV
A006076	M20	70	30	30	EV
A006077	M20	100	35	40	EV
A006078	M24	80	35	24	EV

